

How to Guide - Zion Models

De-Winterization



HOW TO: De-Winterizing

If you winterized only for a short time (less than a week) you can skip to the second step.

First step

You will need 2 gallons of water and 1 cup of fresh bleach. (Bleach loses its potency over time; always start with bleach that is less than 6 months old.)

1. Mix up two gallons of water and one cup of chlorine bleach. Add to the fresh water fill in the driver's door post, using a funnel.
2. This is a good time to get some stuff for spring cleaning of your Roadtrek, so drive around for an hour. Let it sit for a couple more hours.
3. Open the fresh water tank drain valve under the driver's door step, and drain the tank.

This kills any bacteria in the tanks before you distribute them through the entire water system.

Second step

- Fill and drain to ground the fresh water tank. Fill again so that the tank is filled with fresh water, adding a cup of chlorine bleach halfway through the filling process.
- Turn the water pump on.
- Run both hot and cold water through the galley and bathroom sink until all pink antifreeze is out of the lines, and the faucets are running clear. Depress the toilet valve until the water runs clear. Run the outside shower faucets until they are clear.
- Drain the remaining contents of the fresh water tank to ground, and refill with fresh water. You can help get rid of any residual chlorine smell by adding a half cup of vinegar to this tankful, letting it sit a few hours or overnight, and then draining and refilling the tank.
- You do not have to dump the water in your gray and black water tanks after de-winterizing immediately, since it's just water and antifreeze.