
RV ROOF VENT

INSTRUCTIONS AND OPERATING GUIDE



Caution:

NOTE1: Vent fits in standard 14" x 14" RV roof openings.

NOTE2: This vent is using a 5A slow melt fuse. Replacement fuse requires the same ampere.

CAUTION1: Use 12 Volt power only! Connecting you fan to 110 Volt power will damage the internal circuit board. Consult a professional electrician for wiring assistance if necessary.

CAUTION2: DO NOT LEAVE VENT LID OPEN AND UNATTENDED FOR EXTENDED PERIODS OF TIME. HIGH WINDS OR OTHER UNUSUAL CONDITIONS MAY RESULT IN LEAKAGE AND/OR SERIOUS DAMAGE!

CAUTION3: Disconnect main vehicle power before connecting 12 volt DC power to the ventilator.

NOTE1: When in start mode, the rain sensor is off (Need to press Rain Sensor button to start this function). The RS LED is on represent the Rain Sensor function is working.

NOTE2: Note: If your remote is not working. Please reprogram it by pressing POWER button on the Fan and pressing RAIN SENSOR button on the remote at the same time for 4 seconds. If it's still didn't work, please disconnect RV roof fan from main vehicle power and reprogram it again..

OPERATING:

Press POWER button to start the remote, the LED will illuminate.

The LED will be off in 10 seconds if no future operation.

1. **Press FAN POWER button to turn on/off the fan power.**



2. **Press "+" button, the air out at 10% Speed;**



Press it again for more Speed options;

3. **Press "-" button, the air out at 10% Speed;**



Press it again for more Speed options;

4. **Press UP button to open the lid.**



5. **Press DOWN button to close the lid.**




6. **Press the FAN button to turn fan motor OFF/ON at any selected speed.**



7. **Hold down this button in 2 seconds to switch Celsius Or Fahrenheit.**

It shows the temperature of room.



8. **Press RAIN SENSOR button to turn/off the rain sensor.** When in start mode, the rain sensor is off
(Need to press Rain Sensor button to start this function)



NOTE3: The lid can't be opened when the rain sensor sense the water on the fan.
Please turn the Rain Sensor function off if you want to open the lid.